

RISER COVER INSTALLATION

Assembly Instructions

PARTS LIST

TOOLS NEEDED

2x 7219583

1x M4 Allen Key or Internal Hex Drive

1x 5048484-AA (for 20070001) 1x 20047594-AA (for 20070002)



INSTRUCTIONS

STEP 1: Following installation of the seat and riser into the vehicle, obtain the riser cover and hardware from the loose parts package.

STEP 2: Align the riser cover pins to the slot in the riser. (figure 1).

FIGURE 1







STEP 3: Hand start the bolts from the outside of the riser to the weld nuts on the riser cover. (figure 2).

IGURE 2



STEP 4: Torque the fasteners using a 4 mm internal hex drive to 12 Nm. (figure 3).

FIGURE 3



Part numbers: 20070001 and 20070002

Performance Seats, Inc 24801 Capital Blvd , Clinton Twp, MI 48036 USA Main: +1 800-873-2276